

Floor Area Ratio (FAR) – is the total building square footage (i.e., building area) divided by lot size square footage (i.e., site area). $FAR = \text{building area} / \text{site area}$